



Asus Zenbook UX32VD Bottom Panel Replacement

“Prerequisite Only”

Written By: Michael Remmel








TOOLS:


- [Phillips #00 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Bottom Panel



- Remove the twelve 3 mm bottom panel screws with a [T5 Torx Screwdriver](#).

Step 2



- Use a [plastic opening tool](#) to pry along the perimeter of the bottom panel until it can be easily removed.
- Remove the bottom panel from the body of the laptop.
- Set aside the bottom panel.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-03 03:01:08 PM.